

SWEAT BEE® SAFETY CABLE

The following instructions are for attaching the safety cable to a column-mounted Sweat Bee® fan. Consult the complete Sweat Bee Installation Guide for all other aspects of fan installation and safety guidelines.


ATTENTION

The safety cable is a crucial part of the fan and must be installed correctly. If you have questions or require assistance, call Customer Service at 1-877-BIG-FANS.


CAUTION: Do not connect the safety cable to the fan housing on either end of the fan. Do not connect the safety cable to an area near the blades where it could become tangled in the blades.

Parts and Hardware


If you are missing any parts or hardware, contact Customer Service at 1-877-BIG-FANS. *The illustrations below are not to scale.*



Safety Cable



Gripple®



(2) Wire Rope CIP

Installation

To attach the safety cable:

1. Loop the crimped end of the cable around the fan yoke, and then pull the loose end of the cable through the crimped end.
2. Route the cable through the Gripple, around the column, and then back through the Gripple as shown.
3. Pull the loose end of the cable through the Gripple until the cable is drawn tightly around the column.
4. Secure the loose end of the cable with the two wire rope clips and torque to 4.5 ft-lb (6.1 N·m).

Note: To back the safety cable out of the Gripple, insert 1/16 (1.5 mm) Allen wrench into the small hole on the Gripple.

